



## 2021 Ford Bronco Reverse Light Film Instructions

### Part# IAG-BDY-F2050

#### Tools Required:

Squeegee (Supplied)  
Soapy Water  
Heat Gun or Hair Dryer  
Microfiber Towel

#### Mixing:

Soap / water mixture  
5 drops of baby shampoo to 32 oz. water

**Video Instructions Link:** <https://www.iagperformance.com/instructions-iag-bdy-f2050>

1. Apply light film on a calm (no wind), warm day 60° or warmer. Clean the light surface with soapy water. Make sure to clean around the edges of the light. The surface must be clean, dry, and free of any wax before the film is applied.
2. Wash your hands! (Oily or soiled hands leave fingerprints in the adhesive of the light film).
3. Dry fit the film to the light before removing the paper backing to ensure proper fitment. The film kit is cut to size.
4. Remove the backing paper and hold the film with both hands, do not let the adhesive side of the film touch itself or it will be impossible to separate. Spray the adhesive side of the film and the light with the soapy water mix. Position the film up to the light and delicately let it contact the light. Position the film over the clear white surface of the tail light. Make sure the film is able to cover the entire white portion of the light before proceeding.
5. Start to press the film to the light with the squeegee provided, use an up and down motion to remove the water behind the light film. Use your microfiber towel to collect the excess soapy water from around the film. If necessary use a heat gun on the low setting or a hairdryer on the high heat setting to help stretch the film over the light as you apply.
6. When complete go over the outside edge of the light with the squeegee and heat gun/hairdryer to ensure complete overall adhesion.